

# SolidWalk LT (With Moisture Barrier, Lip & Tape) - Installation Instructions



1) Subfloor surface must be clean and dry before installation.



2) Start in a corner. Unroll SolidWalk LT underlayment over subfloor with vapor barrier film (Logo Imprinted Side) **up** facing the ceiling. Be sure tape strip side is next to the wall and overlapping lip is toward the open room.



3) Roll out next row in the same manner butting fiber pad close to first row and under the overlapping lip moisture barrier. Do not overlap fiber pad just moisture barrier lip.



4) Remove tape liner and secure overlapping moisture barrier on top of it. Continue with installation. Seal all open seams with aggressive adhesive plastic tape.



Manufactured by:

